

Fiber-Based Electro-Optic Field-Mapping System




FIG. 1

Fiber-Based Electro-Optic Field-Mapping System

Polarization Control






FIG. 2




detection (input) beam polarization (w.r.t. horizontal axis)



signal (reflected) beam (w.r.t. horizontal axis)

Fiber-Based Electro-Optic Sampling System

GRIN Lens




Fiber-Based Electro-Optic Sampling System
Probe Tip Fabrication Procedure




PR 1827 : 3.5 Krpm (30 sec), 105 C (1 min)


expose without mask (15 sec), develop (90 sec)



PR 1827 : expose (15 sec), develop (50 sec),
hard bake (105 C, 1 min)



mount sample on glass substrate
using clear wax (on the 150 C hot plate)




wet etching : $H_2SO_4 : H_2O_2 : H_2O$
= 1 : 8 : 1
+ few drops of NH_4OH
agitate 30 sec every 30 sec
change etchant every 10 min.



Final probe tip
(released in the hot acetone)

FIG. 4

Fiber-Based Electro-Optic Sampling System Probe Tip Fabrication - (100) GaAs



etching depth ~ 160 μm (7.95 μm/min x 20 min)
(lateral : 130~150 μm, 6.5~7.5 μm/min)








FIG. 5

Fiber-Based Electro-Optic Sampling System Probe Tip Fabrication - (110) GaAs





where,
 $t = 200 / 18.86 (\mu m/min) = 10.6 \text{ min for } 200 \mu m \text{ wafer}$
 $t = 350 / 18.86 (\mu m/min) = 18.6 \text{ min for } 350 \mu m \text{ wafer}$
 $(t = \text{etching time, min})$

▲ $L_i = 1029 \mu m \text{ for } 200 \mu m \text{ wafer,}$
 $= 1427 \mu m \text{ for } 350 \mu m \text{ wafer}$

FIG. 7

Fiber-Based Electro-Optic Sampling System Probe Head Assembly






FIG. 9




FIG. 10




Fig 11

FIG. 12




Fig 12




FIG 13





FIG 14

Characterization - Electric Field Phase



•Over one hour, measured temporal phase stability is $\pm 3^\circ$.

Fig 15

20090929 2512600T






FIG 16



- Frequency domain measurements (2 - 40 GHz):
 $|S_{11}| < -30$ dB with and without probe.

FIG 17



• Effect of probe is equivalent to a lumped shunt capacitance on the order of femtofarads.




Fig 18




FIG 19




FIG 20

Probe Vs Power Meter




FIG 21

Modulation Vs Absorption




FIG 22




FIG 23




FIG 24